

18V ONE+™ 20cm Cordless Brush Cutter (Bare Tool) OBC1820B

RYOBI



- Provides optimum power for cutting tough grass and long weeds
- Brush cutter and trimmer with both blade and trimmer head for versatility
- 20cm hardened steel TriArc™ cutting blade for tough jobs
- Large 30cm line trimmer cutting path to complete tasks quickly
- Soft-grip bike handle design with variable speed control for optimum control



Power	18V
Cutting path with Brushcutter blade [cm]	20
Cutting path with Grass Trimmer blade [cm]	30
Line diameter (mm)	1.6
Weight with battery pack (EPTA) (kg)	5.1
Article Number	5133002619
Battery pack capacity (Ah)	-
Charger included	No
Cutting line diameter (mm)	1.6
EAN Code	4892210141033
Line feed system	Bump head
No. of batteries supplied	0
Sound power level (Lwa) (dB(A))	93.5
Standard equipment	Tri-Arc™ blade, bump feed spool, Vertebrae™ comfort harness
Supplied in	Over 75% recycled cardboard carton
Vibration Level Left Handle [m/s²]	1.6
Vibration Level Right Handle [m/s²]	1.4
Vibration uncertainty (m/s²)	1.5
Weight (without battery) (kg)	4.7

*Registration required for extension from 2-3 years. Please visit our site for full [T&C's](#)