## 18V ONE+ Cordless Brushless HP 30cm Chainsaw RY18CSX30A-0

## **RYOBI**.







- Brushless motor provides maximum torque and efficiency for effortless cutting
- 30cm bar and chain to tackle logs and limbing
- Whisper™ technology reduces the noise levels for users ear protection
- Fast cutting chain speed of 13.2m/s
- Tool-less chain chain tensioning for easy set up and adjustment
- Automatic bar and chain lubrication system for user convenience and consistent chain lubrication
- Mechanical and electrical chain brake system shuts down the tool during an accidental kickback for added safety
- Robust construction and optimum balanced weight distribution for ease of handling

Article Number	5133005465
Battery pack capacity (Ah)	-
Battery type	Li-ion
Chain bar length (cm)	30
Chain pitch [mm]	8.26
Chain speed (m/s)	13.2
Charger included	No
EAN Code	4892210204523
Gauge [mm]	1.09
No. of batteries supplied	0
Power	18V
Power	18V
Standard equipment	Scabbard and bar and chain oil bottle
Supplied in	Recyclable Carton
Tooless chain tensioner	Yes
Weight (without battery) (kg)	3.2
Weight with battery pack (EPTA) (kg)	3.92 (RB1840X)



