

18V ONE+™ Cordless Patio Cleaner with Scrubbing Brush (Bare Tool) RY18PCB-0



- Use across a wide variety of surfaces including decking, astro turf and other hard surfaces meaning less cleaning time and effort for you
- Adjust the telescopic shaft to suit your height which means upright cleaning without bending, stooping or kneeling and taking all the effort out of scrubbing your surfaces
- Ergonomic adjustable two-handle design with overmould grip gives you further cleaning comfort especially over extended use
- Tool-free changing of cleaning heads allows for quick transitions to suit your cleaning task and more time cleaning and less time fiddling
- A variety of brush heads designed to clean different surfaces and detergents are available separately to ensure you get the perfect clean everytime and no matter the surface
- As part of the ONE+™ system for the home and garden, this tool can be powered by any 18V ONE+™ battery!

Power	18 V
Weight with battery pack (EPTA) (kg)	3.9 (RB1820C)
Article Number	5133004729
Battery pack capacity (Ah)	-
Battery type	Li-ion
Charger included	No
EAN Code	4892210185587
No. of batteries supplied	0
Sound power level (Lwa)(dB(A))	80
Standard equipment	Scrubbing Brush
Supplied in	Over 75% recycled cardboard carton
Vibration level (m/s ²)	0.8
Weight (without battery) (kg)	3.5

*Registration required for extension from 2-3 years. Please visit our site for full [T&C's](#)